


Compact Disc Player

Operating Instructions




CDP-CX450

WARNING

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

For the customers in the United States



This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

INFORMATION

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

Owner's Record

The model and serial numbers are located at the rear of the unit. Record the serial number in the space provided below. Refer to them whenever you call upon your Sony dealer regarding this product.

Model No. CDP-CX450


Serial No. _____

for the customers in North America

(Except for customers in the United States)

This appliance is classified as a CLASS 1 LASER product.

The CLASS 1 LASER PRODUCT MARKING is located on the rear exterior.



Welcome!

Thank you for purchasing this Sony Compact Disc Player. Before operating the unit, please read this manual thoroughly and retain it for future reference.

About This Manual

The instructions in this manual are for model CDP-CX450.

Conventions

- Instructions in this manual describe the controls on the player. You can also use the controls on the remote if they have the same or similar names as those on the player.
- The following icons are used in this manual:



Indicates that you can do the task using the remote.



Indicates hints and tips for making the task easier.

TABLE OF CONTENTS

Getting Started

Unpacking	4
Hooking Up the System	4
Connecting Another CD Player	6
Setting Up the Remote	7
Inserting CDs	10

Playing CDs

Playing a CD	13
Using the Display	14
Locating a Specific Disc	16
Specifying the Next Disc to Play	18
Playing the Disc Just Inserted (Easy Play)	19
Playing Discs in Various Modes (Repeat/Shuffle Play)	19
Creating Your Own Program (Program Play)	21
Using the Timer	26
Fading In or Out	26

Storing Information About CDs (Custom Files)

What You Can Do With the Custom Files	27
Labeling Discs (Disc Name)	27
Loading the Custom Files into the Remote	30
Storing Custom File Information Using a Keyboard	32
Storing Specific Tracks (Delete Bank)	32
Grouping Discs (Group File)	33
Classifying Discs According to Artist Name (Artist File)	36
Storing Your Favorite Tracks (Hit List)	39

Using the Player with Another Component

Controlling Another CD Player (Advanced Mega Control)	41
Playing Alternately (No-Delay Play/X-Fade Play)	42
Controlling the Player by Another Unit	43

Additional Information

Precautions	44
Notes on CDs	44
Troubleshooting	45
Specifications	45

Index


Index	46
-------------	----


Unpacking

Check that you received the following items:


- Audio cord (1)
- Video cord (1)
- Remote commander (remote) (1)
- Size AA (LR6) batteries (3)

Inserting batteries into the remote

You can control the player using the supplied remote. Insert three size AA (LR6) batteries (supplied) by matching the + and - ends on the batteries to the diagram inside the battery compartment. Insert the negative (-) end first, then push in and down until the positive (+) end clicks into position. When using the remote, point it at the remote sensor  on the player.



When to replace batteries

If  flashes in the remote's display, replace all the batteries with new alkaline batteries. Use of battery types other than alkaline batteries, such as manganese batteries, may not last longer than the alkaline batteries. The loaded memory in the remote will be retained for a few minutes while you replace the batteries.


Notes

- Do not leave the remote near an extremely hot or humid place.
- Do not drop any foreign object into the remote casing, particularly when replacing the batteries.
- Do not expose the remote sensor to direct sunlight or leave too near lighting apparatuses. Doing so may cause a malfunction.
- If you do not use the remote for an extended period of time, remove the batteries to avoid possible damage from battery leakage and corrosion.

Hooking Up the System

Overview

This section describes how to hook up the CD player to an amplifier. Be sure to turn off the power of each component before making the connections.



What cords will I need?


Audio cord (supplied) (1)

White
(L)
Red
(R)


White
(L)
Red
(R)

Hookups

When connecting an audio cord, be sure to match the color-coded cord to the appropriate jacks on the components: Red (right) to Red and White (left) to White. Be sure to connect firmly to avoid hum and noise.





- **If you have a digital component such as a digital amplifier, D/A converter, DAT, or MD**
Connect the component via the DIGITAL OUT (OPTICAL) connector using an optical cable (not supplied). Take off the cap and plug in the optical cable.
Note that you cannot use fading in or out (page 26) and Time Fade (page 26) functions when making this connection.



Note

When you connect via the DIGITAL OUT (OPTICAL) connector, noise may occur when you play CD software other than music, such as a CD-ROM.

- **You can check the disc information by observing the TV screen when you connect the player and your TV with the video cable.**



- **If you have a Sony component with the CONTROL A1II (or CONTROL A1) jack**


Connect the component via the CONTROL A1II (or CONTROL A1) jack. You can simplify the operations of audio systems composed of separate Sony components. For details, refer to the supplementary "CONTROL A1II Control System" instructions.



Connecting the AC power cord

Connect the AC power cord to a wall outlet.

Note on placement of the player


Be sure to place the player in a flat, horizontal place. If the player is left in a slanted position, it may cause a malfunction or damage the player.






Notes

- Do not connect any player other than the one used as the second player to the 2ND CD IN jacks of this player.
- When connecting a second CD player, do not connect the DIGITAL OUT (OPTICAL) connector of this player to the amplifier.

Changing the command mode of the player

- 1 Press MENU/NO.
- 2 Turn the JOG dial until "Command Mode?" appears in the display.
- 3 Push the JOG dial.
The current command mode appears.




Current command mode

- 4 Turn the JOG dial to select CD1 or CD2, then push the JOG dial again.


Setting Up the Remote**Understanding the 2-way remote system**

The supplied remote operates under a 2-way remote system. While you use the remote and the remote's display is on, the component responds to signals sent from the remote by sending signals back to the remote.



During remote operations, point the remote toward the player at all times.

To avoid unintentional operations, turn off the 2-way remote system of this or connected player when:

- you connect via CONTROL A1/CONTROL A1II two or more components supplied with a remote with the  mark (for example, when you connect this player to another set of this player or certain receiver/amplifier). In this case, you need to turn off the 2-way remote system of the components except the one you want to use as a main unit for the system. When you use the remote, make sure to turn on the main unit.
- you connect this player to a receiver/amplifier supplied with the RM-TP501, RM-TP501E, or RM-LJ301 remote control. In this case, you need to turn off this player's 2-way remote system.

To turn off this player's 2-way remote system, see "To turn off the 2-way remote system" on page 8.

To turn off the 2-way remote system

You may need to turn off the player's 2-way remote system depending on which components you connect to this player. See "Understanding the 2-way remote system" on page 7 to see if you need to do so.

Even though you turn off the player's 2-way remote system, you can use the remote supplied with the player by pointing the remote toward the unit such as a receiver that the 2-way remote system is turned on. In this case, position the player in the proximity of the unit that the 2-way remote system is turned on.

MENU/NO YES

- 1 Press MENU/NO.
- 2 Turning the JOG dial until "2WAY OFF ?" appears in the display window.
- 3 Press YES.

To return to normal setting

After following steps 1 and 2, and "2WAY ON ?" is displayed, then press YES.

If you connect to the Sony CD player CDP-CX260 or CDP-CX88ES, press OPERATE on the transmitter/receiver to turn it off, and set the 2-way remote system of the player to on.

Note



If you use this player with a receiver/amplifier, turn the receiver/amplifier on when using this player.

How to use the remote


Press I/⏻ on the player to turn on the player.

If the following message appears in the remote's display while setting up the remote, point the remote at the main player.

Can't receive
Please turn
this REMOTE
to a main unit




You can select an item shown in the remote's display by moving the cursor (▶). To move the cursor down, push the Easy scroll key downward. To move the cursor up, push the Easy scroll key upward.



Storing player data in the remote

The remote checks and stores the player data such as the command mode sent from the player(s) so that you can use the remote to control the player(s).
Turn on the player before operation.


- 1 Press MENU.




Note the ▼ mark indicates that the menu continues.

Press the Easy scroll key downward to see the next items.


- 2 Move the cursor (▶) to "Set up" by using the Easy scroll key, then press the Easy scroll key.



- 3 Move the cursor to "Player check," then press the Easy scroll key.
The display shows the disc data in the player after "Now player checking..." appears.



When you connect another CD player, the disc data in the second CD player also appears.




Note


When you change the command mode of the player or connect a 2nd player, be sure to perform "Player check."

Adjusting the display contrast of the remote


- 1 Press MENU.



- 2 Move the cursor (▶) to "Set up" by using the Easy scroll key, then press the Easy scroll key.



- 3 Move the cursor to "Contrast adjust," then press the Easy scroll key.




- 4 Adjust the contrast by pressing the Easy scroll key up or down and holding until the desired level of contrast is attained.
- 5 Press the Easy scroll key.


Turning off the LCD back light

You can conserve the remote's batteries by turning off the LCD (Liquid Crystal Display) backlight.


- 1 Press MENU.



- 2 Move the cursor (▶) to "Set up" by using the Easy scroll key, then press the Easy scroll key.



- 3 Move the cursor (▶) to "Back light mode" by using the Easy scroll key, then press the Easy scroll key.




- 4 Move the cursor to "OFF," then press the Easy scroll key.

Note


If you erase all the data stored in the remote (page 31), follow the procedure above to turn the backlight off again.

Inserting CDs


You can insert up to 400 discs into this player.




Top view of the disc slot



- 1 Press I/POWER to turn on the player.
- 2 Open the front cover by pressing OPEN/CLOSE.



- 3 Turn the JOG dial until you find the disc slot where you want to insert a disc, while checking the disc number (written beside every slot and also indicated in the small display).



The disc number at the loading position appears in the display. If the disc has a Disc Name (see page 27), the Disc Name appears instead of the disc number. As you turn the JOG dial, the disc number or the Disc Name changes.

1 GROUP
MULTI CD TEXT NO DELAY CD2

You can classify discs by using the Group File function or Artist Name function. This feature lets you easily find the disc you want to play. For details, see “Grouping discs (Group File)” on page 33 and “Classifying discs according to Artist Name (Artist File)” on page 36.

- 4 Insert a disc with the label side facing right.

After inserting the disc, you can enter the original disc title to replace the disc numbers (see “Labeling discs (Disc Name)” on page 27) so you can locate it easily whenever you want to play it.

- 5 Repeat steps 3 and 4 to insert more discs.
- 6 Close the front cover by pressing OPEN/CLOSE.



The rotary table turns and the disc slot at the loading position is set to the playing position. Always keep the front cover closed except when inserting or removing discs.

Removing CDs

After following steps 1 to 3 of “Inserting CDs” on page 10, remove the discs. Then close the front cover.




To remove discs easily

After following steps 1 to 3 of “Inserting CDs” on page 10, press  (DISC EJECT). The disc in the selected slot moves up and you can remove the disc easily. When you press  again, the disc returns to the loaded position. If the disc does not return to the loaded position, reinsert the disc.

Playing a CD

You can play all the tracks on a disc in the original order (Continuous Play). You can also play up to 400 discs consecutively. Make sure you have inserted the discs correctly as indicated on pages 10 and 11.




- 1 Turn on the amplifier and select the CD playing position.
- 2 Press I/⏻ to turn on the player.
- 3 Press CONTINUE to select ALL DISCS or 1 DISC Continuous Play mode. Each time you press CONTINUE, "ALL DISCS" or "1 DISC" appears alternately in the display.

When you select The player plays

ALL DISCS	All discs in the player consecutively in the order of disc number. Empty disc slots are skipped.
1 DISC	Only the one disc you have selected.

- 4 Turn the JOG dial until the desired disc number or Disc Name (see page 27) appears in the display to select the first disc (ALL DISCS) or the disc you want (1 DISC).



- 5 Push the JOG dial to start playing and adjust the volume on the amplifier. The selected disc is set to the playing position, and the player plays all the discs from the selected one (ALL DISCS) or all the tracks once (1 DISC).

Operations you may want to do during play

To	Do this
Stop playback	Press ■.
Pause	Press .
Resume playing after pause	Press or ▷.
Go to the next disc	Press DISC SKIP + once. Hold down the button to skip other discs.
Go back to the preceding disc	Press DISC SKIP - once. Hold down the button to skip other discs.
Go to a specific track directly	Press the number button of the track on the remote. When you directly locate a track numbered over 10, press >10 first, then the corresponding number buttons.
Go to a point in a track while monitoring the sound	Press ◀◀ (backward)/▶▶ (forward) on the remote and hold down until you find the point.
Go to a point in a track by observing the display	Press ◀◀ (backward)/▶▶ (forward) on the remote and hold down until you find the point during pause. You will not hear the sound during the operation.
Go to the next track	Turn the ◀◀ AMS ▶▶ dial clockwise by one click.
Go back to the preceding track	Turn the ◀◀ AMS ▶▶ dial counterclockwise by one click.
Stop playing and remove the disc	Press OPEN/CLOSE.


When you turn off the player

The player remembers the last playing disc and the play mode: Continuous (on page 13), Shuffle (on page 20), or Program (on page 21). When you turn on the player again, the player plays the same disc in the same play mode.


Note

If "⌂" appears in the large display, the disc has reached the end while you were pressing ▶▶. Turn the ◀◀ AMS ▶▶ dial counterclockwise or press ◀◀ to go back.


Locating a specific track or a point in a track while observing the remote display



- 1 During stop mode, press TRACK.



- 2 Move the cursor (▶) to the desired track by using the Easy scroll key.



- 3 Press the Easy scroll key.
To return to the previous display, press BACK.


Note

When you select a CD TEXT disc, track titles appear in step 2 instead of the track numbers.

Using the Display

You can check stored disc information, such as the Disc Names (see page 27) or Artist Names (see page 36), by using the display.

Unlike a normal CD, a CD TEXT disc includes information such as the disc title or artist name. The display shows the CD TEXT information so that you can check the current disc title, artist name, and track title. When the player detects a CD TEXT disc, "CD TEXT" appears in the display. If your CD TEXT disc has multi-language capacity, "MULTI CD TEXT" appears in the display. If you want to check the information in another language, refer to "Selecting the language of the CD TEXT information" on page 15.




Display information of the normal discs

Display information in stop mode


The display shows the current disc number, total number of tracks, and total playing time of the disc.

Current disc number or Disc Name etc.



Total number of tracks

Total playing time



Current disc number

Display information of the playing disc

While playing a disc, the display shows the current disc number, track number, playing time of the track, and the next disc number.

The large display shows up to 13 characters of the information. When you press SCROLL, all the information scrolls in the display.

The information is displayed as follows:

- When the Artist Name is assigned to the current disc
Disc Name/Assigned Artist Name
- When no Artist Name is assigned to the current disc
Disc Name

Display information of CD TEXT discs

Display information in stop mode

The display shows the disc title. When you press SCROLL, the disc title scrolls in the display. When you assign the artist Name (see page 36), the artist name also appears and scrolls in the display.

Display information while playing a disc

The display shows the disc and track title alternately. When you press SCROLL, the disc title and track title scroll in the display.

The display shows up to 13 characters of the information. When you press SCROLL, all the information scrolls in the display.

The information is displayed as follows:


- When the Artist Name is assigned to the current disc
Disc title of CD TEXT/Assigned Artist Name
- When no Artist Name is assigned to the current disc
Disc title of CD TEXT/Artist name of CD TEXT

Selecting the language of the CD TEXT information

You can select the language used to display the CD TEXT information when you select a CD TEXT disc with multi-language information.

Once you select the language, the display shows the information in the selected language until you turn off the player. If the player cannot read the language memorized in a CD TEXT disc, "other lang." appears.

- 1 Press MENU/NO in stop mode.
"Select lang.?" flashes.



- 2 Push the JOG dial.
The current operating language flashes.

- 3 Turn the JOG dial until the language you want appears in the display.

- 4 Push the JOG dial to select the language.
"Reading text" appears momentarily, then the display shows the information in the selected language.



You can check the current language

- 1 Press MENU/NO while playing a CD TEXT disc.
"Show lang.?" flashes.
- 2 Push the JOG dial.


The current language appears momentarily.

You can also check the current language while selecting a CD TEXT disc without multi-language information.

Note

If you select a CD TEXT disc that does not contain the information of the selected language, the display shows the information in another language according to the disc's priority.

Locating a Specific Disc



Locating a disc on the player

Turn the JOG dial until the desired disc number or Disc Name (see page 27) appears in the display. Push the JOG dial to start play.


To skip discs quickly

Press +100. Each time you press +100, the player skips 100 discs.

Locating a disc by searching for a specific Disc Name (Name Search)

You can search for and locate a desired disc by the first character of the Disc Name (see page 27). The Name Search function can display the Disc Name in alphabetical order.

- 1 Press NAME SEARCH.
"NAME SEARCH" appears in the display.
- 2 Turn the JOG dial to find the desired disc.
As you turn the JOG dial, the Disc Names starting with the input character appear in the display.



The following characters are displayed as the first character.

A B C D E F G H I J K L M N O P Q R S T U V W X
Y Z 0 1 2 3 4 5 6 7 8 9

If "NOT FOUND" appears in the display while inputting the first character with the JOG dial, no disc has been labeled using the input character.

Notes

- When searching for input characters, blanks and symbols before the first character in the Disc Name are ignored.
- When searching for input characters, upper and lower cases cannot be differentiated.

- 3 Push the JOG dial to select the disc.
In Program Play mode, the disc will be added to the end of the program.

To cancel Name Search


Press NAME SEARCH again.

Note

The Name Search function on the player does not work during ALL DISCS shuffle play.

Locating a disc while observing the TV screen

When you connect the player and your TV (see page 5), you can select the disc while observing the TV screen.




- 1 Set your TV to the connected input of the player
The disc information display appears on the TV screen.


Disc number Assigned Artist Name*

No.	Disc Name*	Artist Name*
331	Beethoven:Symphony N	America
332	Mozart:Piano concert	Europe
333	SONYHITS	Orchest
334	Chopin:The piano wor	Poland
335	Vivaldi:Four seasons	Italy o
336	World Jazz hits 2000	David
337	World dance music No	Richard
338	Greatest popular hit	Steve
339	Greatest jazz titles	Michael
340	Super mega hits 2000	Mike

Track title (appears when the current disc is CD-TEXT disc)

* Each time you press SCROLL, the Disc Name and Artist Name interchange.




To locate a disc using the Disc Name data on the remote 

You can search for and locate a desired disc by using the Disc Name data on the remote.

Before following the procedure below, be sure to load the Disc Name data into the remote's memory (see page 30).

- 1 Press MENU.
- 2 Move the cursor (▶) to "Name search" by using the Easy scroll key, then press the Easy scroll key.
- 3 Push the Easy scroll key up or down until the first character in the Disc Name of the CD you want appears.



Each time you push the Easy scroll key up or down, the characters appear in the following order.

A B C D E F G H I J K L M N O P Q R S T U V W X
Y Z 0 1 2 3 4 5 6 7 8 9

- 4 Press the Easy scroll key to input the character you want.
The display shows the Disc Names starting with the input character. The second CD player's disc numbers are displayed in reverse contrast.



If "not found" appears after inputting the first character, no disc has been labeled using the input character.

- 5 Move the cursor to the disc number you want to play, then press the Easy scroll key.


Notes

- Shuffle Play (on page 20) and Program Play (on page 21) are canceled when you use this function on the remote.
- The Disc Names of the 2nd player do not appear when the player is in Artist Play (on page 36) or Group Play (on page 33) mode.


Specifying the Next Disc to Play

You can specify the next disc to play while playing a disc in Continuous or 1 DISC Shuffle Play mode.

While playing a disc, turn the JOG dial. "NEXT DISC" flashes in the display and the disc number or Disc Name (see page 27) changes as you turn the JOG dial. When the desired disc number or Disc Name appears in the display, stop turning the JOG dial.



Next disc number or the Disc Name



Current disc number

After the current disc is played, the next disc you have specified starts playing.


If you want to skip to the next disc right away, push the JOG dial while playing the current disc.

To cancel the disc you have specified

Press CONTINUE twice.

Playing the Disc Just Inserted (Easy Play)

You can play the disc that was just inserted in slot 1 by pressing only one button.



- 1** Open the front cover by pressing OPEN/CLOSE.
- 2** Press EASY PLAY.
Slot 1 moves into loading position.
- 3** Insert the disc in slot 1.
- 4** Press EASY PLAY.
The EASY PLAY button is lit and the player starts playing the disc in slot 1.

Note

The Easy Play function can play only the disc in slot 1.



To cancel the Easy Play function

Press ■.

Playing Discs in Various Modes (Repeat/Shuffle Play)

You can play discs or tracks repeatedly (Repeat Play) in any play mode.

You can also have the player “shuffle” the tracks and play in random order (Shuffle Play). The player shuffles all the tracks on all discs or on the disc you specify.



Playing repeatedly (Repeat Play)

Press REPEAT while playing a disc.

“REPEAT” appears in the display. The player repeats the discs/tracks as follows:

When the disc is played in	The player repeats
ALL DISCS Continuous Play (page 13)	All tracks on all discs
1 DISC Continuous Play (page 13)	All tracks on the current disc
ALL DISCS Shuffle Play (page 20)	All tracks on all discs in random order
1 DISC Shuffle Play (page 20)	All tracks on the current disc in random order
Program Play (page 21)	The same program

To cancel Repeat Play

Press REPEAT twice.




To repeat the current track

While the track you want is being played, press REPEAT one or more times until “REPEAT 1” appears in the display.




To cancel Repeat 1 Play

Press REPEAT.

Playing all tracks on all discs in random order

- 1 Press SHUFFLE repeatedly until “ALL DISCS” and “SHUFFLE” appear in the display.
- 2 Press . ALL DISCS Shuffle Play starts. “ ” appears in the display while the player is shuffling the discs or the tracks.

Playing all tracks on a specified disc in random order

- 1 Press SHUFFLE repeatedly until “1 DISC” and “SHUFFLE” appear in the display.
- 2 Turn the JOG dial until the desired disc number appears in the display. When using the remote, first press DISC, then press the number button of the disc.
- 3 Press . 1 DISC Shuffle Play starts. “ ” appears in the display while the player is shuffling the tracks.

To cancel Shuffle Play

Press CONTINUE.



You can start Shuffle Play while playing

Press SHUFFLE, and Shuffle Play starts from the current track.



You can go to the next disc during 1 DISC Shuffle Play


Press DISC SKIP +.



You can specify the next disc to play during 1 DISC Shuffle Play


Turn the JOG dial to specify the next disc. After all the tracks on the current disc are played in random order, the next disc starts playing. If you want to skip to the next disc right away, push the JOG dial while playing the current disc.

Notes

- You cannot specify the next disc to play during ALL DISCS Shuffle Play.
- Even if you press  or turn off the player during ALL DISCS Shuffle Play, the player remembers which discs or tracks were played and which were not. Therefore, if you want to start ALL DISCS Shuffle Play again from the beginning, be sure to repeat the procedure from step 1.


Creating Your Own Program (Program Play)

You can arrange the order of the tracks and/or discs to create three different programs that are stored automatically. A program can contain up to 32 “step.” One “step” may contain a track or a whole disc. You can make programs using the controls on the remote or on the player. However, the programming procedures are different.




Creating a program on the player


- 1 Press PROGRAM until the desired program number (PROGRAM 1, 2, or 3) appears in the display.
If a program is already stored in the selected program number, the last step of the program appears in the display. When you want to erase the whole program, hold down CLEAR until “CLEAR” appears in the display (see page 22).
- 2 Turn the JOG dial until the desired disc number appears in the display.



- 3 To program a whole disc, skip this step.
Turn the ◀◀ AMS ▶▶ dial until the desired track number appears in the display.



- 4 Push the JOG dial.



- 5 To program other discs/tracks, do the following:

To program	Repeat Step(s)
All tracks of another disc(s)	2 and 4
Other tracks on the same disc	3 and 4
Other tracks on other discs	2 to 4

- 6 Press ▷ to start Program Play.

To cancel Program Play

Press CONTINUE.

The programs remain even after Program Play ends
When you Press ▷ in Program Play mode, you can play the same program again.

When you press PROGRAM to select Program Play during Continuous or Shuffle Play
The program is played after the current track.

The program remains until erased
Even if you replace discs, the programmed disc and track numbers remain. Therefore, the player will play the new disc and track numbers. However, the programmed disc and track numbers that are not found in the player or on the disc are deleted from the program, and the rest of the program is played in the programmed order.

You can select the program number (PROGRAM 1, 2, or 3) by using the remote
Press PROGRAM on the remote repeatedly until the desired program number appears in the display.

Note

If you select Group Play mode (on page 33), Artist Play mode (on page 36), or Hit List (on page 39), Program Play will be canceled.

Checking the programmed order

You can check your program before or after you start playing.

Press CHECK.

Each time you press this button, the display shows the disc and track number of each step in the programmed order. (When a whole disc is programmed as one step, "AL" appears instead of the track number.) After the last step in the program, the display shows "- END -" and returns to the original display.

Changing the programmed order


You can change your program before you start playing.

To	You need to
Erase a track or disc	Press CHECK until the track or disc you don't want appears in the display, then press CLEAR.
Erase the last track or disc in the program	Press CLEAR. Each time you press the button, the last programmed track or disc will be cleared.
Add tracks or discs to the end of the program	Follow the programming procedure.
Erase the whole program completely	Hold down CLEAR until "CLEAR" appears in the display to erase the whole program, then create a new program following the programming procedure.

Erasing the program stored in memory

- 1 Press PROGRAM repeatedly in stop mode until the program number (PROGRAM 1, 2, or 3) you want to erase appears in the display.
- 2 Press and hold CLEAR until "CLEAR" appears in the display.

Creating a program using the remote




- 1 Press PROGRAM until the program number you want (PROGRAM 1, 2, or 3) appears in the display.


- 2 Press DISC.




- 3 Press the number button of the disc.



- 4 To program a whole disc, press ENTER and go to step 6.



- 5** First press >10 then press the number button of the track.
When you select the track number less than 10, press 10/0 first, and then press the corresponding number to enter a track number from 1 to 9.



- 6** To program other discs/tracks, do the following:

To program	Repeat Step(s)
All tracks of another disc(s)	2 to 4
Other tracks on the same disc	5
Other tracks on other discs	2 to 5

- 7** Press ENTER or ▷ to start Program Play.


To cancel Program Play
Press CONTINUE.

You can check or change the program by pressing the CHECK or CLEAR button on the remote .
See page 22.


Creating a program while observing the remote's display

You can create up to eight programs in the remote's memory by using the remote's display. Each program can contain up to 32 steps.


- 1** Press MENU.




- 2** Move the cursor (▶) to "Program input" by using the Easy scroll key, then press the Easy scroll key.




- 3** Move the cursor to the program you want to create, then press the Easy scroll key.



- 4** Press the Easy scroll key.



- 5** Select the desired disc by pushing the Easy scroll key up or down.
To program a whole disc, press the Easy scroll key again.
To program a certain track of the disc, select the desired track by pushing the Easy scroll key up or down, then press the Easy scroll key.



- 6** Repeat steps 4 and 5 to program more tracks or discs.

To finish creating the program, press MENU. To play the program, see "Playing the program you create using the remote's display" on page 25.


To erase a track or disc, move the cursor to the step you want to erase in step 3, then press CLEAR.
To change a disc or track you programmed, move the cursor to the step you want to change in step 3, then press the Easy scroll key. Select the new disc or track following steps 4 and 5.

Notes


- You cannot program the second player's discs and tracks by using the remote.
- The programmed disc and track numbers that are not found in the player or on the disc are deleted from the program, and the rest of the program is played in the programmed order.

Labeling the program


- 1 Press MENU.




- 2 Move the cursor (▶) to "Program input" by using the Easy scroll key, then press the Easy scroll key.




- 3 Move the cursor to the program you want to label, then press the Easy scroll key.



- 4 Push the Easy scroll key up to move the cursor to the program name, then push the Easy scroll key. The flashing cursor (◀) appears.




- 5 Press CAPS to find the desired letter type. Each time you press the button, the letter type changes cyclically among capital letters (AB), small letters (ab), and numbers (12). To select a symbol, select the capital or small letter type.




Letter type

- 6 To input a letter, press the number button corresponding to the desired letter (indicated beside each number button). The cursor disappears and the first space for the Disc Name flashes. Each time you press the button, the letter changes cyclically among the ones indicated beside the button.

To input symbols, press the number button 1 repeatedly until the desired symbol appears in the display.



Example: To select the letter E
Press the number button 3 twice.



To insert a space, press SPACE once.

To input a number, press CAPS twice to change the letter type, then press the desired number button.

- 7 Press another number button or ►► to go to the next space, then repeat steps 4 to 6 to input more characters.
- 8 Press ENTER when you finish inputting characters.




You can label by using the Easy scroll key
Select a character by using the Easy scroll key in step 5.




If you make a mistake while inputting the character(s)

To correct a single character that was input

- 1 Press ►► until the cursor moves next to the incorrect character.



- 2 Press DEL to delete the incorrect character.



- 3 Input the correct character.

To correct the character currently being input


- 1 Press DEL to delete the incorrect character.
- 2 Input the correct character.

To insert a character(s) between the input characters


Press ►► until the cursor moves next to the point you want to insert, and enter the character(s).

Playing the program you create using the remote's display



- 1 Press MENU.




- 2 Move the cursor (►) to "Program play" by using the Easy scroll key, then press the Easy scroll key.



- 3 Select the desired program by pressing the Easy scroll key up or down, then press the Easy scroll key.
Keep the remote point toward the player for few seconds until the program data is completely transmitted.



Program Play starts when the player finishes loading the program data from the remote.
If the player fails in loading, the following message appears. Press the Easy scroll key again.



Note


The program you create using the remote is stored in the player as PROGRAM 1. If you had previously created a PROGRAM 1, it is automatically erased.

Using the Timer

You can start playing a disc at any given time by connecting a timer (not supplied). Refer also to the instructions for the timer if you need help.

TIMER

Play mode buttons




- 1** Press one of the play mode buttons to select the desired play mode.
- 2** Set **TIMER** on the player to **PLAY**.
- 3** Set the timer to the desired time.
The player turns off. When the set time comes, the player turns on and starts playing.
- 4** After you have used the timer, set **TIMER** on the player to **OFF**.

Fading In or Out

You can manually fade the sound in or out to prevent tracks from starting or ending abruptly.

Note that you cannot use this effect when you use the **DIGITAL OUT (OPTICAL)** connector.

FADER



To

Press FADER

Start play fading in

During pause. "FADE" flashes and "FADE IN" appears in the display. The play fades in.

End play fading out

When you want to start fading out. "FADE" flashes and "FADE OUT" appears in the display. The play fades out and the player pauses.

Note

Fading lasts for about 5 seconds.

What You Can Do With the Custom Files

The player can store four types of information called “Custom Files” for each disc. Once you have stored Custom Files for a disc, the player automatically recalls what you have stored whenever you select the disc. Note that Custom Files are erased if you do not use the player for about one month.

You can store this information:

When you use	You can
Disc Name (page 27)	Label discs using up to 20 characters
Delete Bank (page 32)	Delete unwanted tracks and store only the tracks you want
Group File (page 33)	Group discs in up to eight groups, to locate them easily
Artist File (page 36)	Classify discs according to an artist name

Where are Custom Files stored?

Custom Files are stored not on the disc, but in the player’s memory. Therefore you cannot use Custom Files when you play the disc on other players.

If you replace discs with Custom Files

The Custom File information you have stored remains, since the Custom File information is assigned to each slot. Erase all the Custom Files (Disc Name, Delete Bank, Group File, and Artist File) of the old disc, and then file the new disc information in the Custom Files.

Erasing all Custom Files of all discs

- 1 Press MENU/NO.
- 2 Turn the JOG dial until “ALL ERASE ?” appears.
- 3 Push the JOG dial.
“ALL ERASE ??” flashes.
- 4 Push the JOG dial.
“ALL ERASE” appears in the display, and all Custom Files are erased.

Note

When you perform the operation as described above, all of your own settings are deleted and the original factory settings are restored.

Labeling Discs (Disc Name)

You can label discs using up to 20 characters and have the player display the Disc Name each time you select the disc. The Disc Name can be anything you like, such as a title, musician’s name, category, or date of purchase. You can also label the discs in the second player.




When you select a CD TEXT disc

The disc title is automatically stored as the Disc Name. If the disc title has more than 20 characters, only the first 20 characters of the disc title are stored (see page 15). When you replace a disc with a CD TEXT disc, the disc title of the CD TEXT disc is also stored automatically. Note that you cannot change the Disc Name of a CD TEXT disc.



You can label discs while the front cover is open

Labeling discs on the player




- 1 Turn the JOG dial until the disc number to which you want to assign a Disc Name appears in the display.
When you label a disc with the front cover closed, the disc number of the disc at the playing position appears.
When you label a disc with the front cover open, the disc number at the loading position appears.
- 2 Press MENU/NO.
“NAME IN ?” flashes.
- 3 Push the JOG dial.
The flashing cursor () appears.


(continued)

- 4 Turn the JOG dial until the desired character appears in the display.
The cursor disappears and the first space for the Disc Name flashes.
As you turn the JOG dial clockwise, the characters appear in the following order. Turn the JOG dial counterclockwise to go in reverse order.

(space) A B C D E F G H I J K L M N O P Q R S T U
V W X Y Z a b c d e f g h i j k l m n o p q r s t u v w
x y z 0 1 2 3 4 5 6 7 8 9 ! " # \$ % & ' () * + , - . / : ; <
= > ? @ _



- 5 Push the JOG dial to select the character.
The selected character lights up, and the flashing cursor appears at the next space to be input.



To make a correction

Press CLEAR and begin again by inputting the correct characters.


- 6 Repeat steps 4 and 5 to input more characters.
- 7 Press YES to store the Disc Name.
The display shows the Disc Name.



Repeat steps 1 to 7 to assign Disc Names to other discs.

To change the character type quickly while inputting characters

Press SCROLL in step 4 above. The character on the cursor changes to the first character of each character type. Each time you press SCROLL, the character type changes as follows:



Changing the Disc Name

- 1 Follow steps 1 to 3 in "Labeling discs on the player" on page 27 to select the Disc Name you want to change.
- 2 Turn the ◀◀ AMS ▶▶ dial to move the cursor to the position you want to change.
When the cursor position is on a character, the character flashes but when the cursor position is on a blank space, the cursor (␣) appears in the display.

To change characters

Turn the JOG dial until the desired character appears in the display.

To add characters

Push the JOG dial. The new blank space appears next to the selected character, then turn the JOG dial until the desired character appears in the display.

To erase characters

Press CLEAR. The selected character disappears.

To erase all characters for the current Disc Name


Turn the ◀◀ AMS ▶▶ dial to move the cursor to the first character, then press and hold CLEAR until all the characters are erased.


- 3 Repeat step 2 to change more characters.
- 4 Press YES to store the Disc Name.


Erasing the Disc Name

- 1 Follow steps 1 to 3 in "Labeling discs on the player" on page 27 to select the Disc Name you want to erase.
- 2 Turn the ◀◀ AMS ▶▶ dial to move the cursor to the first character, then press and hold CLEAR until all the characters are erased.
- 3 Press YES.
The Disc Name disappears.

Labeling discs using the remote




- 1** Press DISC.
- 2** Press the number button of the disc you want to label, then press ENTER.
- 3** Press NAME INPUT.
The flashing cursor () appears.
- 4** Press CAPS to find the desired letter type.
Each time you press the button, the letter type changes cyclically among capital letters (A), small letters (a), and numbers (1). To select a symbol, select the capital or small letter type. The selected letter type appears in the display.




- 5** To input a letter, press the number button corresponding to the desired letter (indicated beside each number button).
The cursor disappears and the first space for the Disc Name flashes.
Each time you press the button, the letter changes cyclically among the ones indicated beside the button.


To input symbols, press the number button 1 repeatedly until the desired symbol appears in the display.



Example: To select the letter E
Press the number button 3 twice.



To insert a space, press SPACE once.
To input a number, press CAPS twice to change the letter type, then press the desired number button.

- 6** Press  to select the character.
The selected character lights up, and the flashing cursor appears at the next space to be input.
You can also go to the next space by pressing other number buttons.
- 7** Repeat Steps 4 through 6 to input more characters.
- 8** Press ENTER to store the Disc Name.
The Disc Name lights up in the display.




Repeat Steps 1 through 8 to assign Disc Names to other discs.

 If you make a mistake while inputting the character(s)

To correct a character that was input

- 1 Press **◀◀** or **▶▶** until the cursor moves to the incorrect character.



- 2 Press **DEL** to delete the incorrect character.



- 3 Input the correct character.



To correct the character currently being input

- 1 Press **DEL** to delete the incorrect character.
- 2 Input the correct character.

To insert a character(s) between the input characters


Press **◀◀** or **▶▶** until the cursor moves next to the point you want to insert, and enter the character(s).

Note


You cannot input characters during "2nd PLAYER" appears in the remote's display. In this case, press **PLAYER SELECT** so that "2nd PLAYER" disappears from the remote's display.

Loading the Custom Files into the Remote


By loading the player's stored Custom Files into the remote, you can also see the Custom Files in the remote's display. Only the first 13 characters of each Disc Name, Group File, and Artist File can be loaded into the remote. When the Disc Name (Disc Memo) of the 2nd player is loaded to the player, you can load the Disc Name (Disc Memo) of the 2nd player into the remote.



- 1 Press **MENU**.




- 2 Move the cursor (▶) to "DATA loading" by using the Easy scroll key, then press the Easy scroll key.



- 3 Move the cursor (▶) to the desired Custom File by using the Easy scroll key, then press the Easy scroll key. When you want to load all Custom file, move the cursor to "All data," then press the Easy scroll key.

The remote starts reading Custom File data. The loading time may take a few minutes. Point the remote at the player while loading the data.

Keep the remote 1 – 2 m away from the player while loading the data.




- 4 When the remote finishes reading the data, "Data loading complete!" appears in the remote's display.


Note

If you add Disc Names on the player, select "Disc Name" to load them into the remote in Step 3 above.

- 3 Move the cursor to "Memory clear," then press the Easy scroll key.




- 4 If you want to erase all stored data, move the cursor to "yes," then press the Easy scroll key.




- 5 "All memory clear!" appears in the display when all the data is erased.

Erasing all data stored in the remote

- 1 Press MENU.




- 2 Move the cursor (▶) to "Set up" by using the Easy scroll key, then press the Easy scroll key.



Storing Custom File Information Using a Keyboard


You can store the Disc Name for each disc, one by one, using an IBM-compatible PC keyboard* (not supplied).

* The keyboard's power consumption must be 120 mA or less.



- 1 Connect a keyboard to the keyboard jack on the front panel of the player.

- 2 After selecting the desired disc on the player, press the Enter key.
- 3 Input the desired characters, then press the Enter key to store the information.

 **You can delete all characters of a selected item**
While holding down the Shift key, press the Delete key.

Notes

- If the cursor keys do not work correctly and you cannot complete the task using the keyboard, disconnect the keyboard then reconnect it to the player and try again.
- If the keyboard is not a USA model (shown below), the characters may be input differently from those on the keys.

Storing Specific Tracks (Delete Bank)

You can delete unwanted tracks and store only the tracks you want. When you select the disc containing a Delete Bank, the player will play only the remaining tracks.


CONTINUE SHUFFLE

CLEAR

- 1 Press CONTINUE or SHUFFLE before you start playing.
- 2 Turn the JOG dial to select the disc.
- 3 Press CHECK repeatedly until the track you want to delete appears in the display.
- 4 Press CLEAR.
“DELETE” and “OFF” appear in the display.

If you want to recover the track, press CLEAR again.

- 5 Repeat steps 3 and 4 to delete more tracks.

 **You can recover all the tracks you have deleted**
Hold down CLEAR until “ALL ON” appears in the display.


Note

The deleted tracks are skipped even in Shuffle or Program Play modes (when the whole disc containing a Delete Bank is programmed as one step).

Grouping Discs (Group File)

You might find that too many discs make it hard to find the disc you want. This player has a feature that lets you classify discs into eight groups. Each disc can be put into only one group.

Once you classify discs, you can enjoy Continuous, Shuffle, or Repeat Play within a certain group (Group Play).



Assigning discs to groups

- 1** Press CONTINUE or SHUFFLE before you start playing.
- 2** Turn the JOG dial to select the disc you want to assign to a group.
- 3** Press GROUP FILE.
“Select G1-G8” appears in the display.
- 4** Press one of the GROUP1-8 buttons to which you want to assign the disc.
“GROUP FILE” and the group number appear in the display and the disc is assigned to that group.

Deleting discs from a group

- To delete a disc from a group
 - 1** Turn the JOG dial until the disc number you want to delete from the group appears in the display.
 - 2** Press GROUP FILE.
“Select G1-G8” appears in the display.
 - 3** Press CLEAR.
“GROUP ERASE” appears in the display.
- To delete all discs from a group, press CLEAR while holding down whichever GROUP1-8 button you want to clear.

Labeling groups (Group Name)

You can label the preset group number anything you like, such as a category, using up to 13 characters.

Note that you cannot store the Group Name if you have not assigned any disc to the group.

- 1** Press MENU/NO.
“NAME IN ?” flashes.
- 2** Turn the JOG dial until the group number you want to label appears in the display, and then push the JOG dial.
The flashing cursor (␣) appears.
- 3** Turn the JOG dial until the desired character appears in the display.
The cursor disappears and the first space for the Group Name flashes.
As you turn the JOG dial clockwise, the characters appear in the following order. Turn the JOG dial counterclockwise to go in reverse order.

(space) A B C D E F G H I J K L M N O P Q R S T U
V W X Y Z a b c d e f g h i j k l m n o p q r s t u v w
x y z 0 1 2 3 4 5 6 7 8 9 ! " # \$ % & ' () * + , - . / : ; <
= > ? @ _

- 4** Push the JOG dial to select the character.
The selected character lights up, and the flashing cursor appears at the next space to be input.

To make a correction

Press CLEAR and begin again by inputting the correct characters.

- 5** Repeat steps 3 and 4 to input more characters.
See also “Labeling discs on the player” on page 27 for details.
- 6** Press YES to store the Group Name.

Changing the Group Name

- 1** Follow steps 1 and 2 in “Labeling groups (Group Name)” on page 33 to select the Group Name you want to change.
- 2** Turn the **◀◀ AMS ▶▶** dial to move the cursor to the position you want to change.
When the cursor position is on the character, the character flashes, and when the cursor position is on a blank space, the cursor (▬) appears in the display.
To change characters
Turn the JOG dial until the desired character appears in the display.
To add characters
Push the JOG dial. The new blank space appears next to the selected character, then turn the JOG dial until the desired character appears in the display.
To erase characters
Press CLEAR. The selected character disappears.
- 3** Repeat step 2 to change more characters.
- 4** Press YES to store the Group Name.

Erasing a Group Name

- 1** Follow steps 1 and 2 in “Labeling groups (Group Name)” on page 33 to select the Group Name you want to erase.
- 2** Press and hold CLEAR until all the characters are erased.
- 3** Press YES.
The Group Name is erased.

Playing discs in a group on the player (Group Play)

You can enjoy Continuous or Shuffle Play within a group.

- 1** Select the desired play mode before you start playing.

When you select	The player plays
ALL DISCS Continuous Play	All tracks on all discs in the group consecutively
1 DISC Continuous Play	All tracks on the specified disc in the group consecutively
ALL DISCS Shuffle Play	All tracks on all discs in the group in random order
1 DISC Shuffle Play	All tracks on the specified disc in the group in random order

- 2** Press one of the GROUP1-8 buttons to select the group and press **▷**.
Group Play starts from the disc with the lowest number and located closest to the playing position. If the disc at the playing position is put into the selected group, the play starts from that disc.

To cancel Group Play

Press the GROUP1-8 button that was selected.
“GROUP OFF” appears in the display.



During Group Play, you can locate a desired disc within a group by scanning or searching for Disc Names

See “Locating a disc by searching for a specific Disc Name (Name Search)” on page 16, or “To locate a disc by scanning each Disc Name (Name Scan)” on page 17.



You can specify the disc to play when starting Group Play


After selecting the group, turn the JOG dial to select the disc, then push the JOG dial.

Note


If “NO ENTRY” appears in the display, no disc has been put into the selected group.

Starting Group Play while observing the remote's display


Before following the procedure below, be sure to load the Group File data into the remote's memory by following the procedure in "Loading the Custom Files into the remote" on page 30.




- 1 Before you start playing, press MENU.



- 2 Move the cursor (▶) to "Group select" by using the Easy scroll key, then press the Easy scroll key.




- 3 Move the cursor to the desired group, then press the Easy scroll key.
The GROUP button of the player lights up.




- 4 Move the cursor (▶) to select the desired disc by using the Easy scroll key, then press the Easy scroll key to start playing.

To cancel Group Play

Move the cursor to "Group OFF," then press the Easy scroll key. You can also cancel Group Play by pressing the GROUP button.

-  When the player is in the Shuffle play mode
Playback starts by pressing ▷ in step 3.


-  You can specify the disc by pressing the DISC SKIP +/- button

Notes

- When you control another CD player using the remote's display (see page 41), you may not be able to start Group Play, depending on the player. In this case, first press GROUP during "2nd PLAYER" appears in the remote's display, then press the desired number button (1-8) and press ENTER.
- When you add a Group File on the player, load the Group File to the remote also by following the procedure in "Loading the Custom Files into the remote" on page 30.

Classifying Discs According to Artist Name (Artist File)

You can classify discs by storing Artist Names into the player and assigning them to each disc. Each Artist Name can use up to 20 characters. Once you assign an Artist Name to a disc, you can enjoy Continuous, Shuffle, or Repeat Play within discs assigned same Artist Name and you can search for the desired disc easily. You can also store a category name instead of an Artist Name. Up to 200 Artist Names can be stored.



Storing the Artist Name

- 1** Press MENU/NO.
- 2** Turn the JOG dial until "ART.NAME IN?" appears in the display.
- 3** Push the JOG dial.
"New Artist" flashes.
- 4** Push the JOG dial.
The flashing cursor (▣) appears.
- 5** Turn the JOG dial until the desired character appears in the display.
The cursor disappears and the first space for the Artist Name flashes.
As you turn the JOG dial clockwise, the characters appear in the following order. Turn the JOG dial counterclockwise to go in reverse order.

(space) A B C D E F G H I J K L M N O P Q R S T U
V W X Y Z a b c d e f g h i j k l m n o p q r s t u v w
x y z 0 1 2 3 4 5 6 7 8 9 ! " # \$ % & ' () * + , - . / : ; <
= > ? @ _

- 6** Push the JOG dial to select the character.
The selected character lights up, and the flashing cursor appears at the next space to be input.
To make a correction
Press CLEAR and begin again by inputting the correct characters.
- 7** Repeat steps 5 and 6 to input more characters.
See also "Labeling discs on the player" on page 27 for details.
- 8** Press YES to store the Artist Name.

Changing the Artist Name

- 1** Follow steps 1 to 3 in "Storing the Artist Name" on page 36.
- 2** Turn the JOG dial until the artist name you want to change appears in the display, then push the JOG dial.
- 3** Turn the ◀◀ AMS ▶▶ dial to move the cursor to the position you want to change.
When the cursor position is on the character, the character flashes, and when the cursor position is on a blank space, the cursor (▣) appears in the display.
To change characters
Turn the JOG dial until the desired character appears in the display.
To add characters
Push the JOG dial. The new blank space appears next to the selected character, then turn the JOG dial until the desired character appears in the display.
To erase characters
Press CLEAR. The selected character disappears.
- 4** Repeat step 3 to change more characters.
- 5** Press YES to store the Artist Name.

💡 You can also erase the Artist Name while assigning the Artist Name

- 1** In step 2 above, turn the JOG dial until the Artist Name you want to erase appears in the display, then push the JOG dial.
- 2** Press and hold CLEAR until the Artist Name is erased.
- 3** Press YES.
The Artist Name and "ARTIST ERASE?" appears alternately in the display.
- 4** Press YES.
The Artist Name is erased.

Erasing the Artist Name


- 1 Press MENU/NO.
- 2 Turn the JOG dial until "ARTIST FILE?" appears in the display.
- 3 Push the JOG dial.
- 4 Turn the JOG dial until the desired Artist Name appears in the display.
- 5 Press and hold CLEAR for a few seconds.

Note

When you erase the Artist Name, the Artist File of the Artist Name is also erased.

Assigning an Artist Name to a disc (Artist File)

- 1 Turn the JOG dial to select the disc you want to assign an Artist Name.




The disc to be assigned the artist name.

- 2 Press MENU/NO.
- 3 Turn the JOG dial until "ARTIST FILE?" appears in the display.
- 4 Push the JOG dial.
- 5 Turn the JOG dial until the desired Artist Name appears in the display.
The Artist Names are displayed in alphabetical order.



- 6 Press the JOG dial to assign the Artist Name.



You can assign an Artist Name to a disc while the front cover is open

Note

You cannot assign an Artist Name to a disc when no Artist Name is stored. In this case, "ARTIST FILE" does not appear in the display in step 3 above.

Removing the Artist Name from the disc

- 1 Turn the JOG dial to select the desired disc.
- 2 Press MENU/NO.
- 3 Turn the JOG dial until "ARTIST FILE?" appears in the display.
- 4 Push the JOG dial.
- 5 Turn the JOG dial counterclockwise until "FILE ERASE?" appears in the display, then push the JOG dial.
The assigned Artist Name is removed from the selected disc.

Playing discs assigned the same Artist Name (Artist Play)

You can enjoy Continuous or Shuffle Play within discs that are assigned the same Artist Name.

- 1 Select the desired play mode before you start playing.

When you select	The player plays
ALL DISCS Continuous Play	All tracks on all discs assigned same artist name consecutively
1 DISC Continuous Play	All tracks on the specified disc assigned same artist name consecutively
ALL DISCS Shuffle Play	All tracks on all discs assigned same artist name in random order
1 DISC Shuffle Play	All tracks on the specified disc assigned same artist name in random order

- 2 Press ARTIST MODE. ARTIST MODE flashes.
- 3 Turn the JOG dial to select the desired Artist Name.
- 4 Push the JOG dial. ARTIST MODE lights up.
- 5 Turn the JOG dial to select the desired disc, then push the JOG dial. Artist play starts.

To cancel Artist Play

Press ARTIST MODE so that ARTIST MODE goes off.

You can specify the disc to play when starting Artist Play

After selecting the Artist Name, turn the JOG dial to select the disc, then push the JOG dial.


Note

You cannot select an Artist Name if no discs are assigned to that Artist Name.


Playing a specific disc while observing the Artist Name in the remote's display

Once you assign the Artist Name, you can select the disc by selecting the Artist Name displayed in the remote display.


Before following the procedure below, be sure to load the Artist File data into the remote's memory by following the procedure in "Loading the Custom Files into the remote" on page 30.



- 1 Press MENU.




- 2 Move the cursor (▶) to "Artist select" by using the Easy scroll key, then press the Easy scroll key.



Storing Your Favorite Tracks (Hit List)

You can store the tracks you play frequently and select those tracks by checking the track numbers or titles (see page 40) in the Hit List.

You can put up to 32 tracks in the Hit List.



Playing tracks in the Hit List

- 1 Press HIT LIST before you start playing.
The HIT LIST button lights up and "HIT LIST" appears in the display.
- 2 Turn the JOG dial or the ◀◀ AMS ▶▶ dial until the desired track appears in the front panel display.
- 3 Push the JOG dial or press ▷ to start playing.
When using the remote, press ENTER.



The Hit List remains until erased

Even if you replace discs, the Hit List you create remains. Therefore, the player will substitute the new tracks into the Hit List.

Notes

- The track you select in step 2 will be listed as the first track in the Hit List, and you cannot arrange the order of the tracks in the Hit List.
- When you play tracks in the Hit List, the Group, Artist, or Program play is canceled.

Deleting tracks from the Hit List

- 1 Follow steps 1 and 2 in "Playing tracks in the Hit List" on page 40.
- 2 Press CLEAR.
The selected track is deleted from the Hit list.

To delete all the tracks of the Hit List

When the HIT LIST button lights up, press and hold CLEAR while in stop mode until "CLEAR" appears.

Labeling tracks in the Hit List (Hit Title)

You can label tracks in the Hit List in either of the two methods described below.

To label tracks while in play mode

- 1 Press MENU/NO while playing a track in the Hit List.
"HIT NAME ?" appears in the display.
- 2 Push the JOG dial.
The flashing cursor (▣) appears in the display.

- 3 Turn the JOG dial until the desired character appears in the display.
The selected character for the Hit Title flashes.
As you turn the JOG dial clockwise, the characters appear in the following order. Turn the JOG dial counterclockwise to go in reverse order.

(space) A B C D E F G H I J K L M N O P Q R S T U
V W X Y Z a b c d e f g h i j k l m n o p q r s t u v w
x y z 0 1 2 3 4 5 6 7 8 9 ! " # \$ % & ' () * + , - . / : ; <
= > ? @ _

- 4 Push the JOG dial to select the character.
The selected character lights up, and the flashing cursor appears at the next space to be input.

To make a correction

Press CLEAR and begin again by inputting the correct characters.

- 5 Repeat steps 3 and 4 to input more characters.
See also "Labeling discs on the player" on page 27 for details.
- 6 Press YES to store the Hit Title.

To label tracks while in stop mode

- 1 While the HIT LIST button is lit, select the track you want to label by turning the JOG dial or the ◀◀ AMS ▶▶ dial.
- 2 Press MENU/NO.
The flashing cursor (▣) appears in the display.
- 3 Follow steps 3 to 6 in "To label tracks while in play mode" to input the characters.





You can store a CD TEXT disc's track titles in the Hit List

The CD TEXT disc's track title is stored as a Hit Title automatically when the track is put into the Hit List.

Controlling Another CD Player (Advanced Mega Control)

This unit can control a second CD player (see “Connecting another CD player” on page 6). Even when a second CD player is connected, the controls on both of the units will function. When you press the play button on either unit, the operating player stops and the idle player starts. Make sure that “2nd DETECTED” appears in this player’s display after turning on both players. Note that, depending on the player, you may not be able to operate all the functions of the second CD player.

The controls indicated in the illustration below are effective while the MEGA CONTROL button is lit. To operate the master player, press MEGA CONTROL so that the MEGA CONTROL button goes off, and to operate the second player, press MEGA CONTROL so that the MEGA CONTROL button lights up.



- 1 Press MEGA CONTROL on this player.
The MEGA CONTROL button and “2nd” in the display light up. The display shows the current disc number or Disc Name of the second player.
- 2 Select the desired play mode.
To program tracks, use the controls on the second player.
- 3 Press ▷ on this player to start playing.
The play starts and the display shows the current disc, track numbers, and the playing time of the track.
While the MEGA CONTROL button is lit, you can control the second player with the controls on this player.

To control the master player again

Press MEGA CONTROL. The MEGA CONTROL button goes off and you can control the master player.

To control the master player again by using the remote, you have to reselect the master player by pressing PLAYER SELECT on the remote.

To control the second player directly using the supplied remote


While the MEGA CONTROL button is off, press PLAYER SELECT repeatedly until “2nd player” appears in the remote’s display.

To start playback, move the cursor to select the disc, then press the Easy scroll key.

Loading the Disc Names of the second CD player

If the second CD player has the Disc Name function (see page 27), you can load the Disc Names of the second CD player into this player's memory and display them on this player.

- 1 Press MENU/NO.
- 2 Turn the JOG dial until "LOAD 2ndNAME?" flashes in the display.



- 3 Push the JOG dial.
This player starts loading. (Loading takes about one minute.)

Labeling discs of the second CD player

You can label discs of the second CD player or change the Disc Names loaded from the second CD player.

- 1 Press MEGA CONTROL.
The MEGA CONTROL button lights up.
- 2 Turn the JOG dial to select the disc you want to assign a Disc Name to.
If the disc slot you select does not contain a disc, "NO DISC" appears in the display and you cannot assign a Disc Name.
- 3 Press MENU/NO.
"NAME IN?" appears.
- 4 Push the JOG dial.
- 5 Input the new Disc Name following the procedure in "Labeling discs (Disc Name)" on page 27.

Note


The new Disc Names are stored on this player's memory, so you cannot display them on the second CD player.

Playing Alternately (No-Delay Play/X-Fade Play)

When you connect a second player, you can play tracks in this player and those from the second player alternately from any play mode (see "Connecting another CD player" on page 6).

Select one of the following methods:

- **No-Delay Play:** The current player changes at each track. Each time the current player changes to the other player, the other player starts play without a break in sound immediately after the current player ends play. The other player skips the lead-in portion and starts playing from where the sound actually begins.
- **X-Fade Play:** The current player changes at each track or at the specified interval. You can select the interval, 30, 60, or 90 seconds. Each time the current player changes to the other player, the sound from both players is mixed. The current player ends play by fading out, and the other player starts play by fading in.




- 1 Select the desired disc and play mode for each player.
- 2 **When you select No-Delay Play**
Press NO DELAY.
"NO DELAY" appears in the display.

When you select X-Fade Play

Press X-FADE.

"X-FADE" appears in the display.

Each time you press the X-FADE button, the indication appears as follows:



To change the current player each time a whole track is finished, select "at track end."

To change the current player at the specified interval, press X-FADE repeatedly until the interval you want appears in the display.

- 3** Press \triangleright to start playing.
The MEGA CONTROL button lights up when a track in the second player is selected.

To cancel No-Delay/X-Fade Play

Press the corresponding button repeatedly until "NO DELAY" or "X-FADE" disappears from the display. The current player continues playing.



You can change the method (No-Delay or X-Fade) during play

Press the corresponding button (NO DELAY or X-FADE) following the procedure in step 2.



You can start X-Fade at any point of the track

Press FADER during X-Fade Play.
Even after you have set the X-Fade mode and started X-Fade play, you can start X-Fade manually at any point you like. Note that you cannot do this operation while the sound from both players is mixed.


Notes

- Play starts from the second player if you start play while the MEGA CONTROL button is lit.
- When one player has played all the discs or tracks in the player ahead of the other player, play stops.
- Do not use the controls on the second player during No-Delay/X-Fade Play. They may not work correctly.

Controlling the Player by Another Unit

Controlling the player by another unit

When you connect the player to a Sony MD deck compatible with the Mega Control function, or operate a Sony MD deck by using computer software such as "MD Editor," you must set the player as shown below:



- 1** Press MENU/NO.
- 2** Turn the JOG dial until "CONTROL A1 ?" appears in the display window.
- 3** Press YES.

To return to normal setting

After following steps 1 and 2, and "CONTROL A1II ?" is displayed, then press YES.

Notes

- You can perform the operation above correctly only when you operate Disc 1 to Disc 200.
- You cannot operate this player correctly from another player that does not have the CONTROL A1II jack. In this case, operate the other player from this player.

Precautions

On safety

- Caution — The use of optical instruments with this product will increase eye hazard.
- Should any solid object or liquid fall into the cabinet, unplug the player and have it checked by qualified personnel before operating it any further.

On power sources

- Before operating the player, check that the operating voltage of the player is identical with your local power supply. The operating voltage is indicated on the nameplate at the rear of the player.
- The player is not disconnected from the AC power source (mains) as long as it is connected to the wall outlet, even if the player itself has been turned off.
- If you are not going to use the player for a long time, be sure to disconnect the player from the wall outlet. To disconnect the AC power cord (mains lead), grasp the plug itself; never pull the cord.
- The AC power cord must be changed only at a qualified service shop.

On placement

- Place the player in a location with adequate ventilation to prevent heat build-up in the player.
- Do not place the player on a soft surface such as a rug that might block the ventilation holes on the bottom.
- Do not place the player in a location near heat sources, or in a place subject to direct sunlight, excessive dust or mechanical shock.

On operation

- If the player is brought directly from a cold to a warm location, or is placed in a very damp room, moisture may condense on the lenses inside the player. Should this occur, the player may not operate properly. In this case, leave the player turned on for about an hour until the moisture evaporates.

On adjusting volume

- Do not turn up the volume while listening to a portion with very low level inputs or no audio signals. If you do, the speakers may be damaged when a peak level portion is played.

On cleaning

- Clean the cabinet, panel and controls with a soft cloth slightly moistened with a mild detergent solution. Do not use any type of abrasive pad, scouring powder or solvent such as alcohol or benzine.

On transportation


- When transporting the player, open the front cover then remove all the discs from the player and turn the power off.

If you have any questions or problems concerning your player, please consult your nearest Sony dealer.

Notes on CDs

On handling CDs


- To keep the disc clean, handle the disc carefully.
- Do not stick paper or tape on the disc.



- Do not expose the disc to direct sunlight or heat sources such as hot air ducts, nor leave it in a car parked in direct sunlight as there can be considerable rise in temperature inside the car.
- After removing a disc from the disc slot, store the disc in its case.

On cleaning

- Before playing, clean the disc with a cleaning cloth. Wipe the disc from the center out.



- Do not use solvents such as benzine, thinner, commercially available cleaners or anti-static spray intended for vinyl LPs.

Troubleshooting

If you experience any of the following difficulties while using the player, use this troubleshooting guide to help you remedy the problem. Should any problem persist, consult your nearest Sony dealer.



There's no sound.

- ➔ Check that the player is connected securely.
- ➔ Make sure you operate the amplifier correctly.

The CD does not play.

- ➔ There's no CD inside the player ("–NO DISC–" appears). Insert a CD.
- ➔ Insert the CD with the label side facing right.
- ➔ Clean the CD (see page 44).
- ➔ Moisture has condensed inside the player.
Remove the disc and leave the player turned on for about an hour (see page 44).

The remote does not function.

- ➔ Remove obstacles in the path of the remote and the player.
- ➔ Point the remote at the remote sensor  on the player.
- ➔ Be sure to set up the remote correctly.
- ➔ Replace all the batteries in the remote with new ones if  appears in the remote's display.
- ➔ Set the command mode of the remote according to the command mode of the player.

The player functions incorrectly.

- ➔ The microcomputer chips may be operating incorrectly. Disconnect the AC power cord, then connect it back to the wall outlet to reset the player.

Specifications

Compact disc player

Laser	Semiconductor laser ($\lambda = 780 \text{ nm}$) Emission duration: continuous
Laser output	Max 44.6 μW * * This output is the value measured at a distance of 200 mm from the objective lens surface on the Optical Pick-up block with 7 mm aperture.
Frequency response	2 Hz to 20 kHz $\pm 0.5 \text{ dB}$
Dynamic range	More than 93 dB
Harmonic distortion	Less than 0.0045%

Output

	Jack type	Maximum output level	Load impedance
LINE OUT	Phono jacks	2 V (at 50 kilohms)	Over 10 kilohms
DIGITAL OUT (OPTICAL)	Optical output connector	–18 dBm	Wave length: 660 nm
MONITOR OUT	Phono jacks	1 Vp-p	75 ohms, unbalanced sync negative

General

Power requirements

Where purchased	Power requirements
USA	120 V AC, 60 Hz
Australia	240 V AC, 50/60 Hz

Power consumption	18 W
Dimensions (approx.) (w/h/d)	430 × 189 × 537 mm (17 × 7 1/2 × 21 1/4 in.) incl. projecting parts
Mass (approx.)	8.8 kg (19 lbs 7 oz.)

Supplied accessories

See page 4.

Design and specifications are subject to change without notice.

Index

A, B

- Advanced Mega Control 41
- AMS 13
- Artist name 36
- Automatic Music Sensor. *See* AMS

C

- CD TEXT 15
- Changing
 - Artist Name 36
 - Disc Name 28
 - Group Name 34
- Connecting 4
 - another CD player 6
- Continuous Play 13
- Controlling another CD player 41
- Custom Files
 - Artist File 36
 - Delete Bank 32
 - Disc Name 27
 - Group File 33
 - Hit List 39
 - what you can do with 27

D

- Delete Bank 32
- Disc Name 27

E

- Easy Play 19
- Erasing
 - Artist Name 37
 - Custom Files 27
 - Delete Bank 32
 - Disc Name 28
 - Group Name 34
 - Hit List 40

F

- Fading 26

G

- Grouping Discs 33

H

- Handling CDs 44
- Hit List 39
- Hookups 4
 - overview 4

I

- Inserting CDs 10

J, K

- JOG dial 10

L

- Labeling a disc 27
- Loading the Custom Files 30
- Locating
 - by monitoring 13
 - by observing the display 14
 - by scanning 13
 - by observing the TV screen 16
 - directly 17
 - using AMS 13

M, N, O

- Name Scan 17
- Name Search 16
- No-Delay Play 42

P, Q

- Playback
 - Artist Name Play 36
 - Continuous Play 13
 - Easy Play 19
 - Group Play 33
 - Playing alternately 42
 - Program Play 21
 - Repeat Play 20
 - Shuffle Play 20
 - X-Fade Play 42
- Program 21
 - changing 22
 - checking 22
 - erasing 22

R

- Remote control 4
- Repeating 20
- Rotary table 10

S

- Searching. *See* Locating
- Selecting the language 15
- Shuffle Play 20
- Specifying the next disc 18
- Storing
 - information about CDs 27
 - specific tracks 32

T

- Timer play 26
- Troubleshooting 45

U, V, W













- Unpacking 4

X, Y, Z

- X-Fade Play 42

Names of controls

Buttons

- ARTIST MODE 38
- BACK 8, 14
- CAPS 24, 29
- CHECK 22
- CLEAR 21
- CONTINUE 13
- CURSOR ENTER 16
- CURSOR /// 16
- DEL 25, 30
- DISC 17
- DISC SKIP +/- 13
- EASY PLAY 19
- ENTER 17
- FADER 26
- GROUP 35
- GROUP 1 - 8 33
- GROUP FILE 33
- HIT LIST 39
- MEGA CONTROL 41
- MENU 9
- MENU/NO 7, 15, 27, 37
- NAME SCAN 17
- NAME SEARCH 16
- NO DELAY 42
- Number 17
- OPEN/CLOSE 10
- PLAYER SELECT 41
- PROGRAM 21
- REPEAT 20
- SHUFFLE 20
- SCROLL 15
- SPACE 24, 29
- X-FADE 42
- YES 8, 28, 43
-  13
-  13
-  13
-  13
- / 13
- / 13
- > 10 13
- +100 16

Control

- Easy scroll key 8
- JOG dial 7
-  AMS  13


Switches

- TIMER 26
- I/ 10

Jacks

- CONTROL A1II 5
- DIGITAL OUT (OPTICAL) 5
- 2ND CD IN 6

Others

- Disc slots 10
- Display 14
- Front cover 10
- Remote's display 8
- Rotary table 10
-  4, 7

